





BACKYARD SAFARI™ OUT-FITTERS

BASE CAMP SHELTER

**5 YEARS
AND UP**

Whether you're hiking in the woods or simply camping in your backyard, every outdoor enthusiast needs a place to rest. Our BASE CAMP is portable, easy to assemble, and rugged enough to stand up to the elements. Plus, it comes with a Mini Lantern – a must-have for every camper. BASE CAMP is great as a sun shade on hot days. Grab your gear and get back to nature!



CONTAINS:

1 Field Shelter, 1 Carry Bag, 3 Shelter Poles (One cross pole: 40cm x 7 section and two small poles: 42cm x 4 section, 1 Mini Lantern, 1 Carabiner Clip, 1 Collectable Patch and 1 Pop-up Field Guide™

ASSEMBLY INSTRUCTIONS

1. Unfold the Base Camp and lay flat.
2. Assemble the 3 poles by inserting the ends into each other. (FIG. 1)
3. Insert the long pole into the Base Camp and secure at points A. and B. (FIG. 2)
4. Insert one short pole into the Base Camp and secure at points C. and D. (FIG. 3)
5. Insert the other short pole into the Base Camp and secure at points E. and F. (FIG. 3)
6. Tie the intersections of the poles together with the ties already attached to the Base Camp.
7. For increased stability place ground stakes (not included) through the smaller holes in the support tabs and drive into the ground. (FIG. 4)

PUTTING THE BASE CAMP AWAY AFTER USE:

1. Untie the intersections.
2. Release poles from their eyelets
3. **Push** poles out of the Base Camp. **DO NOT PULL.** Pulling the poles will make them collapse making it difficult to take down your Base Camp.
4. Disassemble and fold the poles.
5. Fold the Base Camp and roll it up.
6. Place it into the Carry Bag.

IMPORTANT: The assembly and taking down of your Base Camp should always be carried out by a responsible adult.

WARNING: Keep all flame and heat sources away from the Base Camp fabric.

This product MEEYS the flammability requirements of CPIA-84 The polyester fabric may burn if left in continuous contact with any flam source. The application of any foreign substance to the Base Camp fabric may render the flam retardant properties ineffective.

SUMMIT™

Toys with a twist

© 2011 Summit Products, LLC, Birmingham, AL 35205

www.summittoy.com

PRINTED IN CHINA

CLIP-ON MINI LANTERN

A LITTLE LIGHT ON THE SUBJECT

Clip, carry, or hang this rugged MINI LANTERN. Field ready and within easy reach, it provides instant light and clips right to your Backyard Safari™ FIELD CARGO VEST.

Instructions:

To turn on the MINI LANTERN, slide the front switch to the right. Use the carabiner clip to hang the lantern wherever you want.

⚠ BATTERY CAUTION: READ AND SAVE THESE INSTRUCTIONS.

Only adults should replace batteries. Do not mix old and new batteries or different types of batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Dispose of old batteries promptly and properly. Do not burn or bury batteries. Replace the batteries when the MINI LANTERN stops operating properly or the light becomes dim. Batteries can leak chemicals and harm electronic parts, so remove them if you do not plan to use your MINI LANTERN for several weeks.

- Use only fresh batteries of the required size and recommended type.
- Non-rechargeable batteries are not to be recharged.
- Be sure the batteries are inserted with the correct polarity.
- Exhausted batteries should be removed from the MINI LANTERN.
- The supply terminals are not to be short-circuited.

INSTALLING/CHANGING THE BATTERIES:

The MINI LANTERN requires 3 x 'AAA' batteries (not included). Using a phillips-head screwdriver, loosen the screw on the battery compartment and lift the cover. Remove the battery cover from the bottom of the MINI LANTERN carefully. Install 3 x 'AAA' batteries into the compartment, being careful to match the polarity as indicated (+ and -). Replace the cover over the compartment and tighten the screw.

COMPLIANCE WITH FCC REGULATIONS:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference,
- (2) this device must accept any interference received, including interference that may cause undesired operation

⚠ CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.