

Netgun

NETGUN Instructions

Have you ever seen a bug or insect and wished you knew more about it? Could see it, examine it up close? Perhaps you even thought you saw a bug no one else ever had. What about all those curious colors? Well, now is your chance because with your new Netgun, you can safely capture, examine and learn about all kinds of flying bugs and insects. Not even the fastest bugs can get away! Ready.....set...EXPLORE!

CONTAINS

- 1 Backyard Safari Netgun
- 1 Net with four attached darts
- 4 bug decoy cut outs for practice
- 1 bug decoy stand

USING THE NETGUN:

Carefully remove your new Netgun from its package and read all the instructions thoroughly before use. Once free from the packaging, lay everything out and make sure you have all the required parts. Check to make sure the net and darts are not tangled and then lay it out flat to better check for rips or holes. Are all the darts securely fastened to the net? All set, TERRIFIC! Next, carefully and one at a time, push each dart straight into its space in the Netgun until you hear a "click." Never point to yourself or others while loading the darts. Remember, don't cross the darts or you will tangle the net and you don't want to do that! Okay, the darts are all in place, so now what? Well, next carefully and slowly push the net completely into the net holder, located between the darts. Make sure none of the net is hanging down loose. That's it, your ready to go exploring and capturing! Find your bug, take aim and don't forget, you can use your free hand to balance the Netgun for a clear shot...LAUNCH!! Your bug can be on the ground, in the air, on a plant, or in a tree...your Netgun has a distance of up to 5 feet!! Once you have your sights set on an insect or flying bug and have launched the net, it will come down and gently cover the bug. After carefully lifting up the net, you can then use your Backyard Safari Critter Catcher or Bug Vacuum to capture your find. Then, after examining it, you can either choose to gently place it in a safe Bug Habitat, making sure to give it food, water and proper care or you can let it go free! Just remember, this is a living creature so, always be respectful of nature. After all, you're an explorer now!! Okay a few last things. Your Netgun is intended only for flying bugs and insects, don't use it on people or other animals. Never use it in any way that might cause a rip in the net, remember, flying bugs and insects ONLY!. One last thing, IMPORTANT thing, bugs and insects, like many things in nature, can be endlessly fascinating. However, some of these little critters can bite or sting, especially if they feel threatened or scared. So remember, bees, hornets, wasps...leave those alone. Also the delicate wings of butterflies may be harmed by the net so, those too, should be left

alone. You don't need to harm nature to learn about it, right? So, how did you do? Need a little practice? Well, that's what your decoys are for! Place each of your decoys in a stand, position them as you like and practice, practice PRACTICE!!

CARING FOR THE NETGUN:

Keep the Backyard Safari Netgun clean and dry. If it does get wet, wipe it dry immediately. Use under normal, and safe play conditions only. When not in use, store the Bug Netgun in a clean, dry area and do not leave it exposed to the elements. Watch for any cracks or damage and inspect the net for any holes or rips. Occasionally after use, wipe the Bug Netgun off with a damp cloth before putting it away. Remember, if you follow the instructions, keep your Netgun clean and remember not to leave it outside, it will provide you with tons of fun!

CAUTION

Do not leave your Netgun outside or exposed to the elements.

The Netgun is intended for flying bugs and insects only. Never, EVER aim or shoot your Bug Netgun at anyone, that includes pets and other animals. Doing so could cause harm or injury and after all, we are supposed to be having FUN!

When cleaning your Netgun, USE ONLY WATER AND NEVER HOUSEHOLD PRODUCTS, not even window cleaner.

Do not use your Netgun if the net become torn.

Lastly, BE VERY CAREFUL . Remember, while insects and bugs may be interesting and fun, some insects and bugs may bite or sting if they feel frightened or trapped. You're an explorer, so be smart and careful in the way you treat all living things in nature. The idea is to learn and explore but, it is your responsibility to use the Netgun properly. A good explorer always respects nature.

SUMMIT™

Toys with a twist

© 2008 Summit Products, LLC.

Trussville, AL 35173

PRINTED IN CHINA