

Backyard Safari™

Super Bug Vacuum Instructions

CONTENTS

One Super Bug Vacuum, clear capture core, and extendable nozzle.

An extra regular length nozzle that also locks on to the capture core for close-up bugs.

USING THE SUPER BUG VACUUM

Carefully remove your new Super Bug Vacuum from its package and read all the instructions thoroughly before use. After choosing the desired nose cone length, make sure the nose cone is securely connected to the capture capsule and the trapdoor is open.

Next, find an insect you would like to capture. Place the chosen nose cone over the bug and squeeze the trigger until the insect has been pulled up into the capture capsule. Use only enough vacuum power to gently pull the bug into the capsule.

Once the insect is inside the capture capsule, quickly close the trapdoor/magnifying glass.

Once the insect has been captured, the capsule may be removed from the rest of the Super Bug Vacuum. You may then safely examine the insect with the magnifying glass, release it or transfer it into an appropriate container.

Simply open the trapdoor inside the removed capture capsule by turning the knob on the side until the insect is out. If you wish to transfer the insect into a container, keep the trapdoor closed, place the capture capsule on the open end of the container and then turn the knob to let the insect out.

Replace the capture capsule back on the body of the Super Bug Vacuum, close the trapdoor, replace the nose cone and you're all set. It really is that easy and that fun!

CARING FOR THE SUPER BUG VACUUM

Keep the Super Bug Vacuum clean and dry. If it does get wet, wipe it dry immediately.

Use under normal, and safe play conditions.

When not in use, store the Super Bug Vacuum in a clean, dry area and do not leave it exposed to the elements.

Occasionally after use, wipe the Super Bug Vacuum

off with a damp cloth before putting it away.

Remember, if you follow the instructions, keep the Super Bug vacuum clean, it will provide you with tons of fun.

CHANGING THE BATTERIES

The Super Bug Vacuum requires 6 AA batteries. Alkaline batteries are recommended. Never use rechargeable batteries.

You will need a small screw driver to remove the base grip and access the battery chamber.

- 1.) Using a Phillips screwdriver, loosen the screw on the battery compartment at the base grip of the Super Bug Vacuum and remove the cover.
- 2.) After removing the old batteries, place in the new ones in the compartment as indicated by the polarity symbols.
- 3.) Replace the cover and tighten the screw.

⚠ CAUTION

Do not leave your Super Bug Vacuum outside or exposed to the elements.

Do not use or point the Super Bug Vacuum at people or animals.

Do not try to pick up other small objects, such as coins, rocks or little brothers and sisters. The Super Bug Vacuum is intended only to be used on bugs and insects, trying to pick up other objects may clog the vacuum.

Yes, it is a SUPER Bug Vacuum but, it can't help you pick up your room so, don't try it.

Lastly, remember you are using the Super Bug Vacuum to explore and learn about living creatures in nature. Keep the bugs in a proper, food and air filled area where they can be safe OR look, learn and then let them go safely back where you found them.

⚠ BATTERY CAUTION

Only adults should replace batteries. Do not mix old and new batteries or different types of batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Dispose of old batteries promptly and properly. Do not burn or bury them.

Any batteries installed in your Super Bug Vacuum are for demonstration purposes only and we make no warranty as to the battery life. Replace the batteries when the Super Bug Vacuum stops operating properly.

Batteries can leak chemicals and harm electronic parts, so remove them if you do not plan to use your Super Bug Vacuum for several weeks.

- Use only fresh batteries of required size and recommended type.
- Never use rechargeable batteries.
- Non-rechargeable batteries are not to be charged.
- Be sure the batteries are inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

SUMMIT™

Toys with a twist

© 2007 Summit Products, LLC.

Trussville, AL 35173

PRINTED IN CHINA

