

Ages 3+

Your new Big Fat Pig will stretch as you feed it! The more money you save, the bigger it will get to hold your savings! It even makes piggy noises when you make deposits.

⚠ BATTERY CAUTION!

READ AND SAVE THESE INSTRUCTIONS.

Only adults should replace batteries. Do not mix old and new batteries or different types of batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Dispose of old batteries promptly and properly. Do not burn or bury batteries.

The batteries installed in your Big Fat Pig are for demonstration purposes only and we make no warranty as to the battery life. Replace the batteries when the sound becomes weak. Batteries can leak chemicals and harm electronic parts, so remove them if you do not plan to use your Big Fat Pig for several weeks.

- Use only fresh batteries of the required size and recommended type.
- Never use rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Be sure the batteries are inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

1. Installing/changing the batteries.

Your new Big Fat Pig requires 3 x AG13 batteries. Remove the battery cover from the Pig carefully. Use a Phillips screwdriver to loosen the screw on the battery compartment and lift the cover. Install 3 x AG13 batteries into the compartment, being careful to match the polarity as indicated (+ and -). Replace the cover over the compartment and tighten the screw.

2. Depositing money.

Insert coins into the slot in the top of the Big Fat Pig. The Pig will make a noise each time a coin is inserted and will expand as it gets full.

3. Removing money.

To remove money from the Big Fat Pig, unscrew the cap on the bottom of the Pig and remove the coins.

⚡ **Before playing, please be sure to disconnect the wire connecting the bottom of the Pig from the try me button.**

⚡ **Occasionally wipe the Pig with a damp cloth to keep it clean and looking new. Do not allow water in or near the electronic slot, as this may damage the device.**

⚡ **Modifying or tampering with the Big Fat Pig's internal components can cause it to malfunction and will void any warranty.**

COMPLIANCE WITH FCC REGULATIONS

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:


- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

BIG FAT PIG



© 2007 Summit Products, LLC.
Trussville, Alabama 35173
Made and Printed in China

