



# COUNTING MONEY JUG

## Counting Money Jug Instructions

You don't have to be a financial genius to save money with this Jug. Your Zillions Counting Money Jug makes it fun to save money and keep track of your balance. Put in your spare change and before you know it...you're on your way to becoming a Zillionaire!!

### INSTALLING BATTERIES:

Your Counting Money Jug requires 2 x 'AA' batteries (not included).

The battery compartment is located on the underside of the cork top. Using a Philips head screwdriver, loosen the screw on the battery compartment cover and remove it.

Place the batteries into the compartment, making sure to match the polarity symbols (+ and -) on the batteries to those marked inside the compartment.

Replace the cover and tighten the screw. PERFECT!

### ⚠ BATTERY CAUTION:

Only adults should replace batteries. Do not mix old and new batteries or different types of batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Dispose of old batteries promptly and properly. Do not burn or bury batteries.

Replace the batteries when the Counting Money Jug stops operating properly.

Batteries can leak chemicals and harm electronic parts, so remove them if you do not plan to use your Counting Money Jug for several weeks.

- Use only fresh batteries of the required size and recommended type.
- Never use rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Be sure the batteries are inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

### DEPOSITING COINS:

Don't bother looking for an on/off switch; your new Counting Money Jug doesn't have one! All you need to get started is a coin! To deposit a coin, simply insert the coin into the coin slot located on the lid of the jug. You will notice the amount of the coin just deposited will be displayed on the screen for you to see. That's it! Your new Zillions Counting Money Jug will take it from there! How? Because the coin slot recognizes the coins deposited and keeps a running balance for you no problem!

### TO CLEAR YOUR ACCOUNT BALANCE OR RESET:

First, pull out the cork lid from the Counting Money Jug. Next, look on the underside of the cork; do you see a little hole with a small button inside? That is the reset button! Next, using an object small enough to fit into the hole, press AND hold the reset button. You must hold the reset button down for at least 2 seconds in order for your account to reset to zero. A \$0.00 will display on the screen. Remember, use a small object for the reset button and it only takes a little pressure. Jamming anything into the reset area may damage the system so just be patient and go easy!

### CARING FOR THE ZILLIONS COUNTING MONEY JUG:

Keep the Money Jug and cork lid clean and dry. If any part of the Money Jug does get wet, wipe it dry immediately.

Use and store the Jug properly. Never leave the Jug exposed to the elements such as direct heat or rain.

Handle the Money Jug carefully, do not drop it.

Never pick up your Money Jug by the cork. When you want to move the Jug, pick it up by the handle and support the bottom of the Jug with your other hand.

To keep your Counting Money Jug clean and looking like new, occasionally wipe it with a damp cloth. Remember; never use any kind of house hold cleaning products on your Money Jug. Finally, modifying or tampering with the Counting Money Jug's internal components can cause a malfunction. Remember, if you take care of your Money Jug it will be a fun, easy way for you to save and keep track of your coins.

### COMPLIANCE WITH FCC REGULATIONS:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

**SUMMIT**<sup>™</sup>  
*Toys with a twist*

© 2009 Summit Products. LLC.  
Birmingham, AL 35205  
www.summittoy.com  
PRINTED IN CHINA