

Introductions for the

DELUXE MONEY JUGS

You don't have to be a financial genius to save money with these Jugs. Your Zillionz Set of 2 Deluxe Money Jugs with Coin Recognition makes it fun to save money and keep track of your balance. Put in your spare change and before you know it... you'll have a whole jug full of coins!! Plus, as an added bonus, you'll have a smaller money jug to keep at school or where ever else you may choose!

INSTALLING BATTERIES

Your Zillionz Set of 2 Deluxe Money Jugs requires 2 x AA batteries each. Now, the batteries are included, but not installed.

The battery compartment is located on the underside of each lid.

1. Using a Phillips head screwdriver, loosen the screw on the battery compartment cover and remove it.
2. Place the batteries into the compartment, making sure to match the polarity symbols (+ and -) on the batteries to those marked inside the compartment.
3. Replace the cover and tighten the screw. PERFECT! Remember, each Jug needs it's own batteries.

⚠ CAUTION

- Only adults should replace batteries.
- Replace the batteries when the Jugs stop operating properly or the display becomes dim.
- Do not mix old and new batteries or different types of batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- Use only fresh batteries of the required size and recommended type.
- Dispose of old batteries promptly and properly. Do not burn or bury them.
- If you do not plan to use your Jugs for several weeks, remove the batteries. Batteries can leak chemicals that can harm electronic parts.

DEPOSITING COINS

Don't bother looking for any on/off switch; your new Set of 2 Deluxe Money Jugs doesn't have any. All you need to get started is have a coin handy! To deposit a coin, simply insert the coin into the coin slot located on the Jug lid. Notice, the amount of the coin just deposited, will be displayed on the screen for you to see. That's it! Your new Zillionz Deluxe Money Jugs will take it from there! How? Because the coin slot recognizes the coins deposited and keeps a running balance for you with no problem! You may deposit everything from 0.01 to 1.00 in the larger Jug and 0.01 to 0.25 for the smaller one. Remember, if you want the Deluxe Money Jugs to keep track of your balance you must use coins ONLY. The larger Jug will not recognize paper bills and the smaller Jug won't take anything over 0.25 thru it's coin slot. However, you may remove the lid on either of the Jugs and place paper money in there for safe keeping, it just won't be tallied.

TO CLEAR YOUR ACCOUNT BALANCE OR RESET

First, pull out the lid from which ever Jug you wish to reset. Next, look on the underside of the lid; do you see a little hole with a small button inside? That is the reset button! Using an object small enough to fit into the hole, press AND hold the reset button. You must hold the reset button down for at least 2 seconds in order for your account to reset to zero. A \$0.00 will display on the screen. Remember, use a small object for the reset button and it only takes a little pressure. Jamming anything into the reset area may damage the system so, just be patient and go easy!

CARING FOR THE ZILLIONZ SET OF 2 DELUXE MONEY JUGS

- Keep the Deluxe Money Jugs and their lids clean and dry. If any part of a Deluxe Money Jug does get wet, wipe it dry immediately.
- Use and store the Deluxe Money Jugs properly. Never leave either Jug exposed to the elements such as direct heat or rain.
- Handle the Deluxe Money Jugs carefully, do not drop them.
- Never pick up your Deluxe Money Jug by the lid, not even the smaller one. When you want to move one of the Jugs, pick it up by the middle and support the bottom of the Jug with your other hand.
- To keep your Deluxe Money Jugs clean and looking like new, occasionally wipe them with a damp cloth. Remember, never use any kind of house hold cleaning products on your Money Jugs. Never try to jam anything into your Deluxe Money Jugs. Finally, modifying or tampering with the Deluxe Money Jug's internal components can cause a malfunction. Remember, if you take care of your Deluxe Money Jugs they will be a fun, easy way for you to save and keep track of your coins!

COMPLIANCE WITH FCC REGULATIONS

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

CAUTION: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



© 2008 Summit Products, LLC.
Trussville, Alabama 35173
Printed in China