




Twister Savings Bank

Instruction Sheet

Congratulations on getting your new Zillionz Twister Savings Bank! This Bank is tons of fun and you'll have a great time watching your coins twist and tumble all the way down. Make sure to keep your eyes on the coins, does one coin go down faster than another? Make a bigger noise, create a bigger twist? How many turns does it take for the coins to reach the bottom? Let's find out!

CONTAIN:

- 1 Base
- 1 Funnel Bottom
- 1 Funnel Top
- 2 Coin Slides



So, your bank is COMPLETELY full of coins you have worked hard to save, how do you get them out? Simple, carefully look on the bottom of your bank, remove the plug and grab some coin!

CARING FOR THE TWISTER SAVINGS BANK:

Keep the Twister Savings Bank clean and dry.

Use under normal and safe conditions only. Occasionally, wipe your Twister Savings Bank off with a damp cloth before putting it away.

Remember, if you follow the instructions, keep the Twister Savings Bank clean and remember to keep it in a safe area, it will provide you with loads of fun!

⚠ CAUTION:

Do not leave your Twister Savings Bank outside or exposed to the elements.

Do not put anything into your new Twister Savings Bank besides coins. Remember, trying to force any other object onto the ramps and into Your Twister Bank, will break it.

Keep your Twister Savings Bank in a safe place where it can't be knocked over or damaged.

USING THE TWISTER SAVINGS BANK:

Carefully remove your new Twister Savings Bank from its package and read all the instructions thoroughly before use. Next, check the Twister Bank for any cracks or damage. Okay? Great, grab some coins and let's get started! First, you will need to take the two coin ramps and attach them onto the Twister Bank. Do you see the two areas, one on each side, near the top of the funnel? Done? Perfect! Now make sure the funnel is mounted firmly to the base and that's it, you're all done. Good Job! Do you have your coins ready because it's time to get this Twister Bank going. Place a coin up against the top of the coin ramp and release it. The coin will travel down along the edge and disappear into the bank below going around and around. Here's a neat idea, place one coin against each ramp and watch the coins race each other down. Did you happen to notice that one coin turns one way and the other coin turns in another? You just made your first Twister!

SUMMITTM
Toys with a twist

© 2008 Summit Products, LLC.
Trussville, AL 35173

PRINTED IN CHINA